



BUX39 can also be tried for Q1, we need 15A+, 100V+, <1uS.  
 L1 = 50T turns 0.5mm Cu Wire on Hi-Freq Torroid ?  
 Partially Based on ST Appn. Note.  
 10A Current carrying tracks must be reinforced by copper braids or wires.

Circuit is a design, some of my designs are not yet tested, use only for educational purpose. use as an idea for study only.  
 put 104 CD cap for all ICs from positive to negative close to IC, even if omitted in circuit, for opamps on dual supply two caps.  
 unused inputs of logic and opamps pull up or down to avoid oscillations and noise. connect supply of all chips if not mentioned.  
 "analog ground" and "digital ground" must be linked at power supply only, avoid loops, let grounds radiate from a ground plane.  
 use MFR 1% for all Resistors, 33E means 33 ohms, 22K means 22 kilo ohms, 1M is 1 megohm. 10T tp means ten turn trimpot.  
 '474 CD' is 47 with 4 zeros pF, 470000 pF, 470 nF, 0.47uF, ceramic disc. "pl" is plastic, low leakage multilayer.

**delabs**  
<http://delabs.topcities.com/>  
<http://delabs.netfirms.com/>  
<http://delabs.tripod.com/>  
<http://www.geocities.com/delabs/>  
<http://www.delabs.net/>

<b>delabs circuits and technologies</b>		
Title <b>Battery Charger with L296</b>		
Size B	Document Number <b>del20031</b>	Rev 1
Date: Monday, May 30, 2005	Sheet 1	of 1